(19) Europäisches Patentamt
European Patent Office
Office européen des brevets

(11) EP 0 772 166 B2

(12) **NEW EUROPEAN PATENT SPECIFICATION**

(45) Date of publication and mention of the opposition decision:
12.02.2003 Bulletin 2003/07

(45) Mention of the grant of the patent:
20.01.1999 Bulletin 1999/03

(21) Application number: **95202914.8**

(22) Date of filing: **27.10.1995**

(51) Int Cl.[7]: **G07F 17/12**, E05G 1/08

(54) **A system for monitoring a multiplicity of doors**

Überwachungssystem für eine Vielzahl von Türen

Système pour surveiller une multiplicité de portes

(84) Designated Contracting States:
AT BE CH DE DK ES FR GB GR IE IT LI LU MC NL PT SE

(43) Date of publication of application:
07.05.1997 Bulletin 1997/19

(73) Proprietor: **BANKOM SECURITY SYSTEMS LTD.**
Bnei Brak (IL)

(72) Inventors:
- **Talmom, Gad**
  Kiryat Ono 55222 (IL)
- **Dershowitz, Zvi**
  Givat Shmuel 51905 (IL)

(74) Representative: **Freed, Arthur Woolf et al**
Edward Evans Barker
Clifford's Inn
Fetter Lane
London EC4A 1BZ (GB)

(56) References cited:
WO-A-89/11016
FR-A- 2 526 474
GB-A- 2 253 727
US-A- 5 198 799

EP 0 772 166 B2

Description

FIELD OF THE INVENTION

[0001] The present invention relates to monitoring apparatus generally and more particularly to electro-optical monitoring apparatus.

BACKGROUND OF THE INVENTION

[0002] There exist in the patent literature a variety of patents which deal with monitoring the opening and closing of a door. The following U.S. patents are representative of the prior art: 3,816,745; 3,875,403; 3,987,428; 4,266,124; 4,319,332; 4,324,977; 4,390,867; 4,583,082; 4,650,990; 4,742,337; 4,812,810; 4,841,283; 4,903,009; 4,965,551; 5,015,840; 5,063,288; 5,111,184; 5,134,386 and 5,138,299.

[0003] FR-A-2,526,474 discloses a system comprising the features of the preamble of claim 1.

SUMMARY OF THE INVENTION

[0004] The present invention seeks to provide an improved system for monitoring which is particularly useful for monitoring the opening and closing of a plurality of doors arranged in a generally planar array.

[0005] There is thus provided in accordance with the present invention a system comprising the features of claim 1.

[0006] Preferably each transceiver includes, for at least some of the multiplicity of doors, a plurality of optical transmitters and receivers operative in a plurality of different directions. Each transceiver is preferably autonomously powered.

[0007] In accordance with a preferred embodiment of the present invention each transceiver includes at least one light emitting diode and light sensor. Preferably each transceiver includes a microprocessor.

[0008] Additionally in accordance with a preferred embodiment of the present invention, each transceiver is operative to provide an indication of an open door or inoperative transceiver downstream thereof in a communications chain.

[0009] Preferably, the communications apparatus includes a personal computer and communicates with the transceivers via at least two communications interfaces.

[0010] In accordance with a preferred embodiment of the present invention, the plurality of doors are doors of a bank of safe deposit boxes.

[0011] Additionally in accordance with a preferred embodiment of the present invention the system also includes apparatus for logging door openings and inoperative transceivers on a time based log.

BRIEF DESCRIPTION OF THE DRAWINGS

[0012] The present invention will be more fully understood and appreciated from the following detailed description, taken in conjunction with the drawings in which:

Fig. 1 is a pictorial illustration of a monitoring system constructed and operative in accordance with a preferred embodiment of the present invention;
Fig. 2 is a simplified partially pictorial, partially block diagram illustration of part of the system of Fig. 1;
Fig. 3 is a simplified block diagram of DCU circuitry mounted on each door being monitored in the system;
Fig. 4 is a simplified block diagram of ECU circuitry forming part of the apparatus of Figs. 1 and 2;
Fig. 5 is an electrical schematic illustration of electrical circuitry employed in a preferred embodiment of the ECU, DCU and SCU circuitry;
Figs. 6A, 6B, 6C, 6D, 6E, 6F, 6G, 6H and 6I are flow charts illustrating the operation of the system manager of Figs. 1 and 2;
Figs. 7A and 7B are flow charts illustrating the operation of the SCU circuitry of Figs. 1 - 5;
Figs. 8A, 8B, 8C, 8D, 8E and 8F are flow charts illustrating the operation of the ECU circuitry of Figs. 1 - 5; and
Figs. 9A, 9B, 9C, 9D, 9E, 9F, 9G, 9H and 9I are flow charts illustrating the operation of the DCU circuitry of Figs. 1 - 5.

LIST OF APPENDICES

[0013] Appendix A is a software listing in Intel Intellec - 8 HEX dump format of software resident in the DCU, ECU and SCU circuitry;

[0014] Appendix B is a listing of a sequence of events which characterizes operation of an embodiment of the invention including four DCUs in four different operational cases.

DETAILED DESCRIPTION OF A PREFERRED EMBODIMENT

[0015] Reference is now made to Fig. 1, which is a simplified pictorial illustration of a system for monitoring a plurality of doors, constructed and operative in accordance with a preferred embodiment of the present invention. The system is here shown in the context of monitoring a bank of safe deposit boxes, which is a preferred application. It is to be appreciated, however, that the invention is not limited to this or any other particular application.

[0016] For the purpose of explanation, the bank of safe deposit boxes, indicated generally by reference numeral 20, is arranged in a plurality of vertical columns 22, labeled A - G, and a plurality of horizontal rows 24, labeled 1 - 8. It is to be appreciated that any suitable number of boxes may be monitored in accordance with a preferred embodiment of the present invention.

[0017] In accordance with a preferred embodiment of the present invention, the system includes a multiplicity of door monitoring units 26, hereinafter termed "DCU"s or transceivers, each of which is mounted on the door of a separate box. Communicating with the door monitoring units 26 are a plurality of edge monitoring units 28, hereinafter termed "ECU"s.

[0018] In the illustrated embodiment, a plurality of ECUs 28 are arranged along the bottom of the bank of boxes 20, one ECU being arranged in registration with one column of DCUs 26, such that, for example, the ECU labeled A communicates with the DCUs in column A and so on. Alternatively, the ECUs could be arranged along a vertical edge of the bank 20.

[0019] The ECUs are arranged for communication and are referred to collectively as a common block, hereinafter termed "ECB". A system control unit 32, hereinafter termed "SCU" controls the ECUs 30 and may in turn be controlled by a system manager 34, which may be embodied in software and be operated by an operator using a conventional personal computer.

[0020] Reference is now made to Fig. 2, which illustrates a representative part of the system of Fig. 1. It is seen that each ECU 28 typically comprises an optical transceiver 40, preferably an LED 42 and a light sensor 44, such as a Schmitt photodetector. The optical transceiver pair 40 communicates with a controller 46, which in tum communicates along the ECB block 30 and with the SCU 32.

[0021] Each DCU preferably includes four optical transceivers 40, disposed along each edge thereof, communicating with a controller 50. The optical transceiver pairs 40 of each DCU 26 are arranged in opposite registration with adjacent corresponding optical transceiver pairs 40 on adjacent DCUs 26 and, where appropriate, with an optical transceiver pair 40 of an adjacent ECU 28, such that serial communication of all adjacent DCUs with each other and with adjacent ECUs 28 is provided, as will be described hereinafter in greater detail.

[0022] The four optical transceiver pairs 40 are designated as follows: Two vertically directed pairs, identified by reference numerals 41 and 43 respectively are termed UPPER LINK and LOWER LINK. Two horizontally directed pairs, identified by reference numerals 45 and 47 respectively are termed RIGHT LINK and LEFT LINK.

[0023] For the sake of convenience in notation, correspondingly positioned transceiver pairs on the ECUs and SCUs are also labeled in accordance with the above convention. In practice, for engineering and manufacturing simplicity, the ECUs, SCUs and DCUs may include the same hardware platform. In the ECUs, the RIGHT LINK and LEFT LINK of adjacent transceivers may communicate either by wire, as illustrated in Fig. 2, or optically.

[0024] Reference is now made to Fig. 3, which is a simplified block diagram illustration of the DCU 26. Controller 50 is delineated by dashed lines and includes a CPU 52 and an associated RAM 54 and ROM 56. The CPU 52 communicates via an I/O bus with respective transmit and receive registers 58 and 60. Register 58 communicates via a LED buffer 62 with four LEDS 64, 66, 68 and 70, each directed in a different direction. Register 60 communicates via a sensor buffer 72 with four sensors 74, 76, 78 and 80, each directed in a different direction.

[0025] A power module 82 provides power to the controller 50 and preferably includes an autonomous power source such as solar cells 84 or an RF energy receiver and rectifier assembly 86. The autonomous power source provides electrical power to a power supply 88, which converts the electrical power to voltages appropriate for use by the various elements of the DCU 26.

[0026] Reference is now made to Fig. 4, which is a simplified block diagram illustration of the ECU 28. Controller 46 includes a CPU 102 and an associated RAM 104 and ROM 106. The CPU 102 communicates via an I/O bus with respective transmit and receive registers 108, 134, 110 and 130. Register 108 communicates via a LED buffer 112 with an LED 114. Register 110 communicates via a sensor buffer 116 with a sensor 118.

[0027] Register 130 receives, via a buffer 132, information from an adjacent ECU, if present. Register 134 transmits via a buffer 136 to an adjacent ECU, if present.

[0028] The serial input 103 and serial output 105 from the CPU 102 provide communication with the SCU 32.

[0029] A schematic illustration of a preferred embodiment of DCU, circuitry appears in Fig. 5. The schematic illustration is believed to be self explanatory, accordingly, no additional description thereof is believed to be necessary. Identical circuitry is employed also for the ECU and SCU circuitry. A listing of software resident in the microcontroller of Fig. 5 appears in Appendix A, for DCU, ECU and SCU functionalities.

[0030] The operation of the apparatus of Figs. 1 - 5 will now be explained with particular reference to Figs. 6A - 6I.

[0031] As illustrated in Fig. 6A, in accordance with a preferred embodiment of the invention, the system manager is operative following initialization to confirm that no door is open and that no door has been authorized to be opened. The system manager is then prepared to deal with any one of three events: a timer event, a user input, receipt of a message from the SCU 32 (Fig. 1). Following occurrence of an event, the system manager returns to an idle state.

[0032] The operation of the system manager upon occurrence of a timer event is illustrated in Fig. 6B. If an excessive time has passed since the last message, a report to that effect is logged and an alarm is sounded. Otherwise, a request is transmitted to the SCU 32 to perform a block poll, as will be described hereinbelow.

[0033] The operation of the system manager upon receipt of a message from the SCU is illustrated in Fig. 6C. Four types of messages are dealt with as will be described hereinbelow:

NBIO - NO BOX IS OPEN
RBIO - RIGHT BOX IS OPEN
LBIO - LEFT BOX IS OPEN
ENDP - END OF POLL

[0034] The subroutines dedicated to the above messages NBIO, LBIO, RBIO and ENDP are illustrated in respective Figs. 6F, 6D, 6E and 6G. Each of the subroutines shown in Figs. 6F, 6D and 6E employ a subroutine which is explained hereinbelow with reference to Fig. 6I. Other than this subroutine, the subject matter of Figs. 6F, 6D, 6E and 6G is not believed to require further explanation.

[0035] The operation of the system manager upon receipt of an input from a user is illustrated in Fig. 6H. A user indicates a single door which he is authorized to open and normally provides the requisite identification to a security operative. The system manager notes in a register that the indicated door is authorized to be opened. When the user has completed accessing a given vault via the door, the system manager notes in a register that the indicated door is no longer authorized to open. The system as described herein is configured to only permit one authorized box opening at any given time. Alternatively, the system could be configured to permit more than one authorized box opening at a given time.

[0036] The operation of the system manager upon reception of a message from a SCU, indicating the open status of a door is illustrated in Fig. 6I. The system checks to determine whether the door which is indicated to be open is authorized to be open. If not, an alarm is sounded. In any event, the open status of the door is logged by column and row numbers.

[0037] Reference is now made to Figs. 7A and 7B which illustrate the operation of SCU circuitry 32. Following initialization, the SCU circuitry awaits a poll command from the system manager 34. Upon receipt of the poll command it conducts polling the status of block 20 (Fig. 1).

[0038] Generally speaking, the task of the SCU is to transmit a poll instruction message to a first ECU in response to a poll system instruction from the system manager 34 (Fig. 1) and to then receive the various return messages therefrom. These messages are then retransmitted by the SCU to the system manager 34.

[0039] As illustrated in Fig. 7B, the polling of block 20 is achieved by transmitting a poll message to a first ECU and then awaiting a message from the ECU. If the message is properly received, it is echoed to the system manager 34. If the message is not properly received, the SCU exits the subroutine of Fig. 7B. The subroutine is operative until an ENDP message is received and echoed to the system manager 34.

[0040] Reference is now made to Figs. 8A, 8B, 8C, 8D, 8E and 8F illustrating the operation of the system manager of Figs. 1-5.

[0041] The following notation will be employed in the discusion which follows:

LINK HX - one of the two horizontal links on a transceiver (DCU, ECU or SCU).
LINK 1 - HX - the other one of the two horizontal links on the transceiver (DCU, ECU or SCU).
LINK VX - one of the two vertical links on a transceiver (DCU, ECU or SCU).
LINK 1 - VX - the other one of the two vertical links on the transceiver (DCU, ECU or SCU).

[0042] As seen in Fig. 8A, following initialization, the ECU waits for a wake-up signal and upon receipt thereof handles a start-bit from a LINK HX.

[0043] As illustrated in Fig. 8B, upon receipt of the message along LINK HX, and if the message is successfully received, the ECU circuitry deals with the following types of messages received from LINK HX:

NBIO - NO BOX IS OPEN
RBIO - RIGHT BOX IS OPEN
LBIO - LEFT BOX IS OPEN

ENDP - END OF POLL
POLL - POLL INSTRUCTION

[0044] As illustrated in Fig. 8C, upon receipt of an NBIO, RBIO or LBIO message, the ECU retransmits the same message with the received column and row indices (COL, ROW) changed to (COL+1,ROW) to LINK 1 - HX, i.e. the opposite link on the same transceiver.

[0045] As illustrated in Fig. 8D, upon receipt of an ENDP message from LINK HX, the ECU performs a DCU column poll and transmits an ENDP message with the received (COL, ROW) indication changed to (COL+1,ROW) to link 1 - HX, i.e. the opposite link.

[0046] As illustrated in Fig. 8E, upon receipt of a POLL message from LINK HX, the ECU also transmits a poll message to LINK 1 - HX. If the transmission is not successful it performs a DCU column poll and transmits the result to link 1 - HX. It also transmits a ENDP message with a column indication 0 to link 1 - HX.

[0047] As seen in Fig. 8F, the ECU transmits a POLL message to the most adjacent DCU (transceiver). If the transmission is not successful, the ECU transmits an NBIO message with indices (0,0) to LINK HX for ultimate transmittal to the SCU 32 and the system manager 34.

[0048] If the transmission is successful, the ECU awaits a message from the adjacent DCU. If such a message is not received successfully, the ECU exits the subroutine. If a message is successfully received from the adjacent DCU, it is dealt with depending on the type of message, i.e. LBIO, RBIO or NBIO.

[0049] In the event of receipt of any of the above three types of messages the ECU transmits a message of the same type to a link HX for ultimate transmittal to the SCU 32 and the system manager 34. The index of the message is a column index 0 and a row index equal to the received index incremented by +1.

[0050] In the event of receipt of RBIO and LBIO messages, the ECU remains in the subroutine awaiting further messages. If an NBIO message is received, the ECU exits the subroutine.

[0051] Reference is now made to Figs. 9A, 9B, 9C, 9D, 9E, 9F, 9G, 9H, 9I and 9J which are flow charts illustrating the operation of the DCU circuitry of Figs. 1 - 5.

[0052] As illustrated in Fig. 9A, upon supply of power to the DCU circuitry and initialization thereof, the DCU remains in a dormant state until it is awakened up by a received signal. The received signal may come from a source which is vertically separated from the DCU or a source which is horizontally separated from the DCU. Once the received signal has been dealt with, the DCU returns to its dormant state.

[0053] As seen in Fig. 9B, if the signal is received from a source that is horizontally separated from the DCU, the DCU retransmits the communication back to the source. If, however, as seen in Fig. 9C, the signal is received from a source that is vertically separated from the DCU, the DCU checks if the message has been correctly received. If so, each message is handled separately and when it has been handled, the DCU returns to its dormant state.

[0054] The description of the handling of the various types of messages is provided with reference to the drawings in accordance with the following table:

MESSAGE TYPE	FIGURE
POLL	Fig. 9D
NBIO	Fig. 9G
RBIO	Fig. 9H
LBIO	Fig. 9I

[0055] Fig. 9D illustrates handling of a POLL message from a LINK VX and indicates that the received POLL message is retransmitted to an opposite link, LINK 1 - VX. If the transmission is not successful, the DCU transmits the status of its right and left neighbors back to link VX and also transmits an NBIO message with index 0 to link VX.

[0056] Transmission of the status of the right and left neighbors is illustrated in Fig. 9E. An inquiry is made as to whether the right neighbor door is open. If so, an RBIO message is transmitted to link VX with index 0. An inquiry is made if the left neighbor door is open. If so, an LBIO message is transmitted to link VX with index 0.

[0057] Reading status of a neighbor is illustrated in Fig. 9F and includes the steps of communicating with a neighboring DCU. If the communication is successful, an indication is provided that the neighboring door is closed. If the communication is not successful, an indication is provided that the neighboring door is open.

[0058] Handling of an NBIO message is illustrated in Fig. 9G and includes transmitting the status of the right and left neighbors as described hereinabove and afterwards transmitting an NBIO message with an ROW index incremented by +1 to the opposite link 1 - VX.

[0059] Handling of an RBIO message is illustrated in Fig. 9H and includes transmitting an RBIO message with a ROW index incremented by +1 to the opposite link 1 - VX.

[0060] Handling of an LBIO message is illustrated in Fig. 9I and includes transmitting an LBIO message with an ROW index incremented by +1 to the opposite link 1 - VX.

[0061] It will be appreciated by persons skilled in the art that the present invention is not limited by what has been particularly shown and described hereinabove. Rather the scope of the present invention is defined only by the claims which follow:

APPENDIX A

Hex File Dump of Door Control Unit (DCU)

[0062]

```
:10000300750801E508D39404500878087401 26F6AE
:10001300 50F122C2A7D200750A00E50AD394075013
:10002300 4A750BFFA294400A150BE50B700201E819
:10003300 80F2E5095401B40103D38001C39201A204
:10004300 0192A7A200300101B39200750BFFA294A5
:10005300 B3400A150BE50B700201E880F1E509C313
:10006300 13F509780A740126F650AF750BFFA294B5
:10007300 400A150BE50B7002806B80F2A20092A779
:10008300 750BFFA294B3400A150BE50B7002805564
:10009300 80F1750BFFA294400A150BE50B700280EB
:1000A300 4480F2A200B392A7750BFFA294B3400A57
:1000B300 150BE50B7002802D80F1750BFFA29440A8
:1000C300 0A150BE50B7002801C80F2D2A7750BFF9B
:1000D300 A294B3400A150BE50B7002800880F1115E
:1000E300 0031103D322D2A7C322C2A5D200750A00EB
:1000F300 E50AD39407504A750BFFA297400A150BE4
:10010300 E50B700221BE80F2E5095401B40103D36B
:10011300 8001C39201A20192A5A200300101B39212
:10012300 0000750BFFA297B3400A150BE50B70022174
:10013300 BE80F1E509C313F509780A740126F65068
:10014300 AF750BFFA297400A150BE50B7002806B8E
:10015300 80F2A20092A5750BFFA297B3400A150B7C
:10016300 E50B7002805580F1750BFFA297400A15CD
:10017300 0BE50B7002804480F2A200B392A5750BCD
:10018300 FFA297B3400A150BE50B7002802D80F197
:10019300 750BFFA297400A150BE50B7002801C80BC
:1001A300 F2D2A5750BFFA297B3400A150BE50B70AE
:1001B300 02800880F111031103D322D2A5C322C206
:1001C300 A6D200750A00E50AD39407505C750B01AB
:1001D300 750C00A295B3400F780B120705E50C458B
:1001E300 0B700241DC80ECE5095401B40103D380B8
:1001F300 01C39201A20192A6A200300101B39200B1
:10020300 750B01750C00A295B3B3400F780B120761
:10021300 05E50C450B700241DC80EBE509C313F5E2
:10022300 09780A740126F6509D750B01750C00A21E
:10023300 95B3400F780B120705E50C450B7002418F
:10024300 DC80ECA20092A6750B01750C00A295B39D
:10025300 B3400F780B120705E50C450B700280794C
:10026300 80EB750B01750C00A295B3400F780B1250
:10027300 0705E50C450B7002805F80ECA200B3928A
:10028300 A6750B01750C00A295B3B3400F780B1242
:10029300 0705E50C450B7002803F80EB750B01757C
:1002A300 0C00A295B3400F780B120705E50C450B24
:1002B300 7002802580ECD2A6750B01750C00A29507
:1002C300 B3B3400F780B120705E50C450B700280A2
:1002D300 0880EB11031103D322D2A6C322C2A4D2F6
:1002E300 0000750A00E50AD39407505C750B01750C81
:1002F300 00A296B3400F780B120705E50C450B706F
:10030300 0261FA80ECE5095401B40103D38001C30F
:10031300 9201A20192A4A200300101B39200750BD5
```

```
:1003230001750C00A296B3B3400F780B120705E5D5
:100333000C450B700261FA80EBE509C313F50978EC
:100343000A740126F6509D750B01750C00A296B335
:10035300400F780B120705E50C450B700261FA801C
:10036300ECA20092A4750B01750C00A296B3B340E6
:100373000F780B120705E50C450B7002807980EBB3
:10038300750B01750C00A296B3400F780B1207058D
:10039300E50C450B7002805F80ECA200B392A4755C
:1003A3000B01750C00A296B3B3400F780B1207052F
:1003B300E50C450B7002803F80EB750B01750C005B
:1003C300A296B3400F780B120705E50C450B70029C
:1003D300802580ECD2A4750B01750C00A296B3B3F3
:1003E300400F780B120705E50C450B70028008805F
:1003F300EB11031103D322D2A4C322A80A7600D29D
:1004030000D202750D01750B00E50BD39407503034
:10041300C2A71103D2A71103A294B39201A201B3FD
:100423004008A80AE6250DA80AF6E50DC333F50D25
:10043300A200300101B39200780B740126F650C973
:10044300C2A71103D2A71103A294300001B3400243
:10045300C202C2A71103D2A71103A294300001B3B1
:100463005002C202C2A71103D2A71103A2945002E1
:10047300C202A20222A80A7600D200D202750D019E
:10048300750B00E50BD394075030C2A51103D2A519
:100493001103A297B39201A201B34008A80AE6256B
:1004A3000DA80AF6E50DC333F50DA200300101B323
:1004B3009200780B740126F650C9C2A51103D2A588
:1004C3001103A297300001B34002C202C2A5110377
:1004D300D2A51103A297300001B35002C202C2A5F4
:1004E3001103D2A51103A2975002C202A20222A8AD
:1004F3000A7600D200D202750D01750B00E50BD30D
:10050300940750 2FC2A61103D2A61103A2959201FC
:10051300A201B34008A80AE6250DA80AF6E50DC313
:1005230033F50DA200300101B39200780B7401265C
:10053300F650CAC2A61103D2A61103A29530000138
:10054300B35002C202C2A61103D2A61103A200B382
:10055300309501B35002C202C2A61103D2A6110301
:10056300A295B35002C202A20222A80A7600D200C8
:10057300D202750D01750B00E50BD39407502FC202
:10058300A41103D2A41103A2969201A201B34008BD
:10059300A80AE6250DA80AF6E50DC333F50DA2005A
:1005A300300101B39200780B740126F650CAC2A43D
:1005B3001103D2A41103A296300001B35002C20268
:1005C300C2A41103D2A41103A200B3309601B35005
:1005D30002C202C2A41103D2A41103A296B3500211
:1005E300C202A20222E50E9006EC25E073850F09F4
:1005F30085100A71FE22850F0985100A91782285DC
:100603000F0985100A91F222850F0985100AB16D31
:0106130022C4
:0806EC00A1F0A1F9C102C10B4C
:10061400E50D9006F425E073850E09111622850E6A
:1006240009 1EC22850E0931C222850E0951E022FE
:0806F400C11CC122C128C12E66
:10063400E50F6401F50D74E0F50ED1144032850F19
:100644000D74C0F50ED11492022002 CE50F700453
```

```
:10065400C2808002C287800AE50F7004D2808002C3
:10066400D287E50F64017004C2808002C287800CC7
:10067400E50F64017004D2808002D28722E50F6402
:1006840001F50DE51004F50ED11492022285110E28
:1006940075101275 0F00B1E85021E51254E0B4E072
:1006A4000BE511F50F851210D134800FE51254E0DB
:1006B400B4C00885110F851210D18122C2AF758094
:1006C400FF7590FF75A0FF75B0FFA294B34009C2F7
:1006D40082751100D191D282A297B34009C2857567
:0806E4001101D191D28580E2E1
:080705000816B6FF02181622C7
:030000000206FCF9
:0906FC0075812175D0000206C0D1
:00000001FF
```

Hex File Dump of Edge Control Unit (ECU)

[0063]

```
:10000300750801E508D3940450087808740126F6AE
:1000130050F122C2A7D200750A00E50AD394075013
:100023004A750BFFA294400A150BE50B700201E819
:1000330080F2E5095401B40103D38001C39201A204
:100043000192A7A200300101B39200750BFFA294A5
:10005300B3400A150BE50B700201E880F1E509C313
:1000630013F509780A740126F650AF750BFFA294B5
:10007300400A150BE50B7002806B80F2A20092A779
:10008300750BFFA294B3400A150BE50B7002805564
:1000930080F1750BFFA294400A150BE50B700280EB
:1000A3004480F2A200B392A7750BFFA294B3400A57
:1000B300150BE50B7002802D80F1750BFFA29440A8
:1000C3000A150BE50B7002801C80F2D2A7750BFF9B
:1000D300A294B3400A150BE50B7002800880F1115E
:1000E300031103D322D2A7C322C2A5D200750A00EB
:1000F300E50AD39407504A750BFFA297400A150BE4
:10010300E50B700221BE80F2E5095401B40103D36B
:100113008001C39201A20192A5A200300101B39212
:1001230000750BFFA297B3400A150BE50B70022174
:10013300BE80F1E509C313F509780A740126F65068
:10014300AF750BFFA297400A150BE50B7002806B8E
:1001530080F2A20092A5750BFFA297B3400A150B7C
:10016300E50B7002805580F1750BFFA297400A15CD
:100173000BE50B7002804480F2A200B392A5750BCD
:10018300FFA297B3400A150BE50B7002802D80F197
:10019300750BFFA297400A150BE50B7002801C80BC
:1001A300F2D2A5750BFFA297B3400A150BE50B70AE
:1001B30002800880F111031103D322D2A5C322C206
:1001C300A6D200750A00E50AD39407505C750B01AB
:1001D300750C00A295B3400F780B1207C9E50C45C7
:1001E3000B700241DC80ECE5095401B40103D380B8
:1001F30001C39201A20192A6A200300101B39200B1
:10020300750B01750C00A295B3B3400F780B120761
:10021300C9E50C450B700241DC80EBE509C313F51E
:1002230009780A740126F6509D750B01750C00A21E
:1002330095B3400F780B1207C9E50C450B700241CB
:10024300DC80ECA20092A6750B01750C00A295B39D
:10025300B3400F780B1207C9E50C450B7002807988
:1002630080EB750B01750C00A295B3400F780B1250
:1002730007C9E50C450B7002805F80ECA200B392C6
:10028300A6750B01750C00A295B3B3400F780B1242
:1002930007C9E50C450B7002803F80EB750B0175B8
:1002A3000C00A295B3400F780B1207C9E50C450B60
:1002B3007002802580ECD2A6750B01750C00A29507
:1002C300B3B3400F780B1207C9E50C450B700280DE
:1002D3000880EB11031103D322D2A6C322C2A4D2F6
:1002E30000750A00E50AD39407505C750B01750C81
:1002F30000A296B3400F780B1207C9E50C450B70AB
:100303000261FA80ECE5095401B40103D38001C30F
:100313009201A20192A4A200300101B39200750BD5
```

```
:100323000175OC00A296B3B3400F780B1207C9E511
:100333000C450E700261FA80EBE509C313F50978EC
:100343000A740126F6509D750B01750C00A296B335
:10035300400F780B1207C9E50C450B700261FA8058
:10036300ECA20092A4750B01750C00A296B3B340E6
:100373000F780B1207C9E50C450B7002807980EBEF
:10038300750B01750C00A296B3400F780B1207C9C9
:10039300E50C450B7002805F80ECA200B392A4755C
:1003A3000B01750C00A296B3B3400F780B1207C96B
:1003B300E50C450B7002803F80EB750B01750C005B
:1003C300A296B3400F780B1207C9E50C450B7002D8
:1003D30080258OECD2A4750B01750C00A296B3B3F3
:1003E300400F780B1207C9E50C450B70028008809B
:1003F300EB11031103D322D2A4C322A80A7600D29D
:1004030000D202750D01750B00E50BD39407503034
:10041300C2A71103D2A71103A294B39201A201B3FD
:100423004008A80AE6250DA80AF6E50DC333F50D25
:10043300A200300101B39200780B740126F650C973
:10044300C2A71103D2A71103A294300001B3400243
:10045300C202C2A71103D2A71103A294300001B3B1
:100463005002C202C2A71103D2A71103A2945002E1
:10047300C202A20222A80A7600D200D202750D019E
:10048300750B00E50BD394075030C2A51103D2A519
:100493001103A297B39201A201B34008A80AE6256B
:1004A3000DA80AF6E50DC333F50DA200300101B323
:1004B3009200780B740126F650C9C2A51103D2A588
:1004C3001103A297300001B34002C202C2A5110377
:1004D300D2A51103A297300001B35002C202C2A5F4
:1004E3001103D2A51103A2975002C202A20222A8AD
:1004F3000A7600D200D202750D01750B00E50BD30D
:10050300940750 2FC2A61103D2A61103A2959201FC
:10051300A201B34008A80AE6250DA80AF6E50DC313
:1005230033F50DA200300101B39200780B7401265C
:10053300F650CAC2A61103D2A61103A29530000138
:10054300B35002C202C2A61103D2A61103A200B382
:1005530030950 B35002C202C2A61103D2A6110301
:10056300A295B35002C202A20222A80A7600D200C8
:10057300D202750D01750B00E50BD39407502FC202
:10058300A41103D2A41103A2969201A201B34008BD
:10059300A80AE6250DA80AF6E50DC333F50DA2005A
:1005A3003001013392007 0B740126F650CAC2A43D
:1005B3001103D2A41103A296300001B35002C20268
:1005C300C2A41103D2A41103A200B3309601B35005
:1005D30002C202C2A41103D2A41103A296B3500211
:1005E300C202A20222E50E9007A725E073850F0938
:1005F30085100A71FE22850F0985100A91782285DC
:100603000F0985100A91F222850F0985100AB16D31
:0106130022C4
:0807A700A1F0A1F9C102C10B90
:10061400E50D9007AF25E073850E09111622850EAE
:100624000911EC22850E0931C222850E0951E022FE
:0807AF00C11CC122C128C12EAA
:10063400C287D28675150075OD0074E0F50ED114CD
:1006440050457515FF75130F7514A0A294B3500689
```

```
:10065400E5144513700280077813120 7C980EC75FE
:100664000E00751012750F00B1E8C0D0E5144513E3
:1006740060030D38001C392F0D0D082F05007E5121A
:10068400045 41FF515804E750D0174E0F50ED11458
:1006940050437515FF75130F7514A0A297B3500638
:1006A400E5144513700280077813120 7C980EC75AE
:1006B4000E01751012750F00B1E8C0D0E514451392
:1006C4006003D38001C392F0D0D082F05007E512CA
:1006D40004541FF515E51564FF601685110DE51525
:1006E400232354FC24E0F50ED1149203300302C2F8
:1006F40086D28722E5166401F50DE517F50ED114AF
:10070400500280 11E516F511D13485160D74D0F51B
:100714000ED114920422E50F6401F50DE51004F5E1
:100724000ED114920222E5166401F511D134E516B6
:10073400 6401F50DE51704F50ED114920422851811
:100744000E751019750F00B1E85035E51954F0F520
:10075400 1AE51AB4E00CE518F50FE519F510F11ACD
:10076400801EE51AB4F00CE518F516E519F517D155
:10077400F8800DE51AB4D008851816851917F12AE2
:1007840022C2AF7580FF7590FF75A0FF75B0FFA200
:10079400964005751803F142A2954005751802F1BB
:0307A4004280ECA4
:10080000758920758840758DF3758BF375987275B1
:10081000870022A298400280FA859921C298E5219A
:1008200022A298501885992 3C298E523B4130CE5A9
:10083000236411600611 13F52380F480E4A299402B
:100840000280DEC2998522992 2752600E52685243C
:10085000838525821207B7E4936015E526852483F6
:10086000852582 1207B7E493F5221121052680DC45
:010870002265
:0907B7002582F58250020583221F
:0807C9000816B6FF0218162203
:030000000207C034
:0907C00075812775D00002078540
:00000001FF
```

Hex File Dump of Site Control Unit (SCU)

[0064]

```
:0E07F000425800E52004040004550OD0A0095
:10000300752101E521D3940B50087821740126F65C
:1000130050F122C2A7D203752300E523D3940750DE
:100023004A7524FFA294400A1524E524700201E8CE
:1000330080F2E5225401B40103D38001C39204A2E8
:10004300049 2A7A203300401B392037524FFA29480
:10005300B3400A1524E524700201E880F1E522C3C8
:1000630013F5227823740126F650AF7524FFA2946A
:10007300400A1524E5247002806B80F2A20392A744
:10008300 7524FFA294B3400A1524E5247002805519
:1000930080F17524FFA294400A1524E524700280A0
:1000A3004480F2A203B392A77524FFA294B3400A3B
:1000B3001524E5247002802D80F17524FFA294405D
:1000C3000A1524E5247002801C80F2D2A77524FF50
:1000D300A294B3400A1524E5247002800880F1112C
:1000E300031103D322D2A7C322C2A5D203752300CF
:1000F300E523D39407504A7524FFA297400A152499
:10010300E524700221BE80F2E5225401B40103D339
:10011300 8001C39204A20492A5A203300401B39206
:1001230003752 4FFA297B3400A1524E52470022126
:10013300BE80F1E522C313F5227823740126F6501D
:10014300AF7524FFA297400A1524E5247002806B43
:1001530080F2A20392A57524FFA297B3400A152447
:10016300E5247002805580F17524FFA297400A159B
:1001730024E5247002804480F2A203B392A575247F
:10018300FFA297B3400A1524E5247002802D80F165
:10019300 7524FFA297400A1524E5247002801C8071
:1001A300F2D2A57524FFA297B3400A1524E5247063
:1001B30002800880F111031103D322D2A5C322C206
:1001C300A6D203752300E523D39407505C7524025C
:1001D3007525C0A295B3400F7824120810E5254574
:1001E30024700241DC80ECE5225401B40103D38086
:1001F30001C39204A20492A6A203300401B39203A2
:1002030075240275 25C0A295B3B3400F7824120854
:1002130010E5254524700241DC80EBE522C313F58C
:1002230022782374 0126F6509D7524027525C0A2F9
:1002330095B3400F7824120810E525452470024138
:10024300DC80ECA20392A67524027525C0A295B3A7
:10025300B3400F7824120810E525452470028079F5
:1002630080EB7524027525C0A295B3400F78241244
:1002730008 10E5254524700280 5F80ECA203B39249
:10028300A67524027525C0A295B3B3400F78241236
:1002930008 10E5254524700280 3F80EB7524027524
:1002A30025C0A295B3400F7824120810E5254524F4
:1002B3007002802580ECD2A67524027525C0A29514
:1002C300B3B3400F7824120810E525452470028 04B
:1002D3000880EB11031103D322D2A6C322C2A4D2F6
:1002E30003752300E523D39407505C752402752519
:1002F300C0A296B3400F7824120810E525452470 58
:10030300026 1FA80ECE5225401B40103D38001C3F6
```

```
:100313009204A20492A4A203300401B392037524AD
:10032300027525C0A296B3B3400F7824120810E5D6
:10033300254524700261FA80EBE522C313F5227888
:10034300237401 26F6509D7524027525C0A296B329
:10035300400F7824120810E5254524700261FA80C5
:10036300ECA20392A47524027525C0A296B3B340F0
:100373000F78241 20810E525452470028079 80EB5C
:10038300752402 7525C0A296B3400F782412081075
:10039300E5254524700280 5F80ECA203B392A47527
:1003A30024027525C0A296B3B3400F782412081017
:1003B300E5254524700280 3F80EB7524027525C036
:1003C300A296B3400F7824120810E5254524700245
:1003D300802580ECD2A47524027525C0A296B3B300
:1003E300400F7824120810E525452470028008 8008
:1003F300EB11031103D322D2A4C322A8237600D284
:1004030003D20575260175240 0E524D394075030E3
:10041300C2A71103D2A71103A294B39204A204B3F7
:100423004008A823E62526A823F6E526C333F526A8
:10043300A203300401B392037824740126F650C951
:10044300C2A71103D2A71103A294300301B3400240
:10045300C205C2A71103D2A71103A294300301B3AB
:100463005002C205C2A71103D2A71103A2945002DE
:10047300C205A20522A8237600D203D20575260160
:100483007524 00E524D394075030C2A51103D2A5E7
:100493001103A297B39204A204B34008A823E6254C
:1004A30026A823F6E526C333F526A203300401B3B9
:1004B3009203782474012 6F650C9C2A51103D2A56C
:1004C3001103A297300301B34002C205C2A5110371
:1004D300D2A51103A297300301B35002C205C2A5EE
:1004E3001103D2A51103A2975002C205A20522A8A7
:1004F300237600D203D20575260175240 0E524D3A3
:10050300940750 2FC2A61103D2A61103A2959204F9
:10051300A204B34008A823E62526A823F6E526C3AC
:1005230033F526A203300401B39203782474012621
:10053300F650CAC2A61103D2A61103A29530030135
:10054300B35002C205C2A61103D2A61103A203B37C
:1005530030950 1B35002C205C2A61103D2A61103FE
:10056300A295B35002C205A20522A8237600D203A6
:10057300D20575260175240 0E524D39407502FC2B4
:10058300A41103D2A41103A2969204A204B34008B7
:10059300A823E62526A823F6E526C333F526A203DA
:1005A3003004013392037824740126F650CAC2A41E
:1005B3001103D2A41103A296300301B35004C280E5
:1005C300C205C2A41103D2A41103A203B33096013E
:1005D300B35004C281C205C2A41103D2A41103A261
:1005E30096B35004C282C205A20522E52790076F85
:1005F30025E07385282285292371FE2285282285FB
:1006030029239178228528228529239 1F22285287E
:0706130022852923B16D22AD
:08076F00A1F6A1FFC108C111B0
:10061A00E52690077725E07385272211162285277C
:10062A002211EC2285272231C22285272251E0227B
:08077700C122C128C12EC134CA
:10063A00C2AF7580FF7590FF75A0FF75B0FF1207F6
```

```
:10064A007F750851E50864506005E508B4700280BA
:10065A00071207?2F50880EC750A00D286D28774D1
:10066A0002F52674F0F527D11A5007D2027509024D
:10067A00801E7403F52674F0F527D11A5007D202AA
:10068A00750903800BC202751C07751DF01207C895
:10069A00200202E16DC201A201407D750BEA750CD0
:1006AA0060C200A200402BE509B40308A296B3B3C6
:1006BA004002D200E509B40208A295B3B34002D2BF
:1006CA0000780B120810E50C450B7004D200D20119
:1006DA0080D1E50C450B700B751C07751DF31207CD
:1006EA00C880338509277529OD752800B1EE502475
:1006FA00E50D54F0B4D004D2018017E50D54F0B4DE
:10070A00E010E50D540FFEE50A240FF8A606050AC7
:10071A00C2868002C287C1A1751C07751DF6120721
:10072A00C8E50A6035750E00E50A14C3950E402A1D
:10073A00E50E240FF8E654032430F51A1207A0E553
:10074A000E240FF8E60303543F54032430F51A121B
:10075A0007A0780E740126F650CE751C07751DF990
:05076A001207C8C14B9D
:10077F007589207588407 58DF3758BF37598727533
:10078F00870022A298400280FA859919C298E5192C
:10079F0022A298501885991BC298E51BB4130CE53B
:1007AF001B64116006F192F51B80F480E4A299405E
:1007BF000280DEC299851A9922751E00E51E851CDE
:1007CF0083851D821207FEE4936015E51E851C8349
:1007DF00851D821207FEE493F51AF1A0051E80DC39
:0107EF0022E7
:0907FE002582F5825002058322D8
:080810000816B6FF02181622BB
:030000000020807EC
:0908070075812A75D00002063A41
:00000001FF
```

APPENDIX B

Sequence of Events

[0065] This document describes the sequence of events which occurs in the system for each of the following cases.

- Case 1 - All doors closed
- Case 2 - A single authorized door is open
- Case 3 - A single unauthorized door is open
- Case 4 - Two doors are open, one is authorized and one is not.

[0066] For the purpose of this description the system includes the following elements:

- A system manager
- A Single SCU which is connected to the ECU labeled ECU1.
- Four ECUs and 16 DCU which are configures in the following manner:

DCU4.4	DCU3.4	DCU2.4	DCU1.4
DCU4.3	DCU3.3	DCU2.3	DCU1.3

(continued)

DCU4.2	DCU3.2	DCU2.2	DCU1.2
DCU4.1	DCU3.1	DCU2.1	DCU1.1
ECU4	ECU3	ECU2	ECU1

Case 1 - All Doors Closed

[0067]

	SOURCE	DEST.	MESSAGE CONTENTS
1.	System	SCU	POLL
2.	SCU	Right Link	POLL (Transmission fails)
3.	SCU	ECU1	POLL
4.	ECU1	ECU2	POLL
5.	ECU2	ECU3	POLL
6.	ECU3	ECU4	POLL
7.	ECU4	Next ECU	POLL (Transmission fails)
8.	ECU4	DCU4.1	POLL
9.	DCU4.1	DCU4.2	POLL
10.	DCU4.2	DCU4.3	POLL
11.	DCU4.3	DCU4.4	POLL
12.	DCU4.4	Next DCU	POLL (Transmission fails)
13.	DCU4.4	DCU3.4	ARE YOU THERE?
14.	DCU3.4	DCU4.4	YES
15.	DCU4.4	DCU4.3	NBIO 0
16.	DCU4.3	DCU3.3	ARE YOU THERE?
17.	DCU3.3	DCU4.3	YES
18.	DCU4.3	DCU4.2	NBIO1
19.	DCU4.2	DCU3.2	ARE YOU THERE?
20.	DCU3.2	DCU4.2	YES
21.	DCU4.2	DCU4.1	NBIO 2
22.	DCU4.1	DCU3.1	ARE YOU THERE?
23.	DCU3.1	DCU4.1	YES
24.	DCU4.1	ECU4	NBIO 3
25.	ECU4	ECU3	NBIO 4,0
26.	ECU3	ECU2	NBIO 4,1
27.	ECU2	ECU1	NBIO 4,2

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
28.	ECU1	SCU	NBIO 4,3
29.	SCU	System	NBIO 4,3; The system interprets this to mean that DCU4.4 could not communicate with a DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
30.	ECU4	ECU3	ENDP 0
31.			
32.	ECU3	DCU3.1	POLL
33.	DCU3.1	DCU3.2	POLL
34.	DCU3.2	DCU3.3	POLL
35.	DCU3.3	DCU3.4	POLL
36.	DCU3.4	Next DCU	POLL (Transmission fails)
37.	DCU3.4	DCU4.4	ARE YOU THERE?
38.	DCU4.4	DCU3.4	YES
39.	DCU3.4	DCU2.4	ARE YOU THERE?
40.	DCU2.4	DCU3.4	YES
41.	DCU3.4	DCU3.3	NBIO 0
42.	DCU3.3	DCU4.3	ARE YOU THERE?
43.	DCU4.3	DCU3.3	YES
44.	DCU3.3	DCU2.3	ARE YOU THERE?
45.	DCU2.3	DCU3.3	YES
46.	DCU3.3	DCU3.2	NBIO 1
47.	DCU3.2	DCU4.2	ARE YOU THERE?
48.	DCU4.2	DCU3.2	YES
49.	DCU3.2	DCU2.2	ARE YOU THERE?
50.	DCU2.2	DCU3.2	YES
51.	DCU3.2	DCU3.1	NBIO 2
52.	DCU3.1	DCU4.1	ARE YOU THERE?
53.	DCU4.1	DCU3.1	YES
54.	DCU3.1	DCU2.1	ARE YOU THERE?
55.	DCU2.1	DCU3.1	YES
56.	DCU3.1	ECU3	NBIO 3
57.	ECU3	ECU2	NBIO 4,0
58.	ECU2	ECU1	NBIO 4,1
59.	ECU1	SCU	NBIO 4,2
60.	SCU	System	NBIO 4,2; The system interprets this to mean that DCU3.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
61.	ECU3	ECU2	ENDP 1
62.	ECU2	DCU2.1	POLL
63.	DCU2.1	DCU2.2	POLL
64.	DCU2.2	DCU2.3	POLL
65.	DCU2.3	DCU2.4	POLL
66.	DCU2.4	Next DCU	POLL (Transmission fails)
67.	DCU2.4	DCU3.4	ARE YOU THERE?
68.	DCU3.4	DCU2.4	YES
69.	DCU2.4	DCU1.4	ARE YOU THERE?
70.	DCU1.4	DCU2.4	YES
71.	DCU2.4	DCU2.3	NBIO 0
72.	DCU2.3	DCU3.3	ARE YOU THERE?
73.	DCU3.3	DCU2.3	YES
74.	DCU2.3	DCU1.3	ARE YOU THERE?
75.	DCU1.3	DCU2.3	YES
76.	DCU2.3	DCU2.2	NBIO 1
77.	DCU2.2	DCU3.2	ARE YOU THERE?
78.	DCU3.2	DCU2.2	YES
79.	DCU2.2	DCU1.2	ARE YOU THERE?
80.	DCU1.2	DCU2.2	YES
81.	DCU2.2	DCU2.1	NBIO 2
82.	DCU2.1	DCU3.1	ARE YOU THERE?
83.	DCU3.1	DCU2.1	YES
84.	DCU2.1	DCU1.1	ARE YOU THERE?
85.	DCU1.1	DCU2.1	YES
86.	DCU2.1	ECU2	NBIO 3
87.	ECU2	ECU1	NBIO 4,0
88.	ECU1	SCU	NBIO 4,1
89.	SCU	System	NBIO 4,1; The system interprets this to mean that DCU2.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
90.	ECU2	ECU1	ENDP 2
91.	ECU1	DCU1.1	POLL
92.	DCU1.1	DCU1.2	POLL

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
93.	DCU1.2	DCU1.3	POLL
94.	DCU1.3	DCU1.4	POLL
95.	DCU1.4	Next DCU	POLL (Transmission fails)
96.	DCU1.4	DCU2.4	ARE YOU THERE?
97.	DCU2.4	DCU1.4	YES
98.	DCU1.4	DCU1.3	NBIO 0
99.	DCU1.3	DCU2.3	ARE YOU THERE?
100.	DCU2.3	DCU1.3	YES
101.	DCU1.3	DCU1.2	NBIO 1
102.	DCU1.2	DCU2.2	ARE YOU THERE?
103.	DCU2.2	DCU1.2	YES
104.	DCU1.2	DCU1.1	NBIO 2
105.	DCU1.1	DCU2.1	ARE YOU THERE?
106.	DCU2.1	DCU1.1	YES
107.	DCU1.1	ECU1	NBIO 3
108.	ECU1	SCU	NBIO 4,0
109.	SCU	System	NBIO 4,0; The system interprets this to mean that DCU 1.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
110.	ECU1	SCU	ENDP 3
111.	SCU	System	ENDP 3; The system interprets this to mean that the polling of 4 columns has been completed. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.

Case 2 - A Single Authorized Door is Open

[0068] The door to which DCU2.3 is attached is open. This door has been authorized to be open.

	SOURCE	DEST.	MESSAGE CONTENTS
1.	System	SCU	POLL
2.	SCU	Right Link	POLL (Transmission fails)
3.	SCU	ECU1	POLL
4.	ECU1	ECU2	POLL
5.	ECU2	ECU3	POLL
6.	ECU3	ECU4	POLL
7.	ECU4	Next ECU	POLL (Transmission fails)

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
8.	ECU4	DCU4.1	POLL
9.	DCU4.1	DCU4.2	POLL
10.	DCU4.2	DCU4.3	POLL
11.	DCU4.3	DCU4.4	POLL
12.	DCU4.4	Next DCU	POLL (Transmission fails)
13.	DCU4.4	DCU3.4	ARE YOU THERE?
14.	DCU3.4	DCU4.4	YES
15.	DCU4.4	DCU4.3	NBIO 0
16.	DCU4.3	DCU3.3	ARE YOU THERE?
17.	DCU3.3	DCU4.3	YES
18.	DCU4.3	DCU4.2	NBIO 1
19.	DCU4.2	DCU3.2	ARE YOU THERE?
20.	DCU3.2	DCU4.2	YES
21.	DCU4.2	DCU4.1	NBIO 2
22.	DCU4.1	DCU3.1	ARE YOU THERE?
23.	DCU3.1	DCU4.1	YES
24.	DCU4.1	ECU4	NBIO 3
25.	ECU4	ECU3	NBIO 4,0
26.	ECU3	ECU2	NBIO 4,1
27.	ECU2	ECU1	NBIO 4,2
28.	ECU1	SCU	NBIO 4,3
29.	SCU	System	NBIO 4,3; The system interprets this to mean that DCU3.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
30.	ECU4	ECU3	ENDP 0
31.	ECU3	DCU3.1	POLL
32.	DCU3.1	DCU3.2	POLL
33.	DCU3.2	DCU3.3	POLL
34.	DCU3.3	DCU3.4	POLL
35.	DCU3.4	Next DCU	POLL (Transmission fails)
36.	DCU3.4	DCU4.4	ARE YOU THERE?
37.	DCU4.4	DCU3.4	YES
38.	DCU3.4	DCU2.4	ARE YOU THERE?
39.	DCU2.4	DCU3.4	YES

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
40.	DCU3.4	DCU3.3	NBIO 0
41.	DCU3.3	DCU4.3	ARE YOU THERE?
42.	DCU4.3	DCU3.3	YES
43.	DCU3.3	DCU2.3	ARE YOU THERE? (Transmission fails)
44.	DCU3.3	DCU3.2	RBIO 0
45.	DCU3.2	DCU3.1	RBIO 1
46.	DCU3.1	ECU3	RBIO 2
47.	ECU3	ECU2	RBIO 3,0
48.	ECU2	ECU1	RBIO 3,1
49.	ECU1	SCU	RBIO 3,2
50.	SCU	System	RBIO 3,2; The system interprets this to mean that DCU3.3 could not communicate with the DCU to its right. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 is attached is open. Because this door is authorized to open, the system logs the event but does not sound the alarm.
51.	DCU3.3	DCU3.2	NBIO 1
52.	DCU3.2	DCU4.2	ARE YOU THERE?
53.	DCU4.2	DCU3.2	YES
54.	DCU3.2	DCU2.2	ARE YOU THERE?
55.	DCU2.2	DCU3.2	YES
56.	DCU3.2	DCU3.1	NBIO 2
57.	DCU3.1	DCU4.1	ARE YOU THERE?
58.	DCU4.1	DCU3.1	YES
59.	DCU3.1	DCU2.1	ARE YOU THERE?
60.	DCU2.1	DCU3.1	YES
61.	DCU3.1	ECU3	NBIO 3
62.	ECU3	ECU2	NBIO 4,0
63.	ECU2	ECU1	NBIO 4,1
64.	ECU1	SCU	NBIO 4,2
65.	SCU	System	NBIO 4,2; The system interprets this to mean that DCU3.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound that alarm.
66.	ECU3	ECU2	ENDP 1
67.	ECU2	DCU2.1	POLL
68.	DCU2.1	DCU2.2	POLL
69.	DCU2.2	DCU2.3	POLL (Transmission fails)

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
70.	DCU2.2	DCU3.2	ARE YOU THERE?
71.	DCU3.2	DCU2.2	YES
72.	DCU2.2	DCU1.2	ARE YOU THERE?
73.	DCU1.2	DCU2.2	YES
74.	DCU2.2	DCU2.1	NBIO 0
75.	DCU2.1	DCU3.1	ARE YOU THERE?
76.	DCU3.1	DCU2.1	YES
77.	DCU2.1	DCU1.1	ARE YOU THERE?
78.	DCU1.1	DCU2.1	YES
79.	DCU2.1	ECU2	NBIO 1
80.	ECU2	ECU1	NBIO 2,0
81.	ECU1	SCU	NBIO 2,1
82.	SCU	System	NBIO 2,1 ; The system interprets this to mean that DCU2.2 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 is attached is open. Since this door is authorized to be open, the system logs the event but does not sound the alarm.
83.	ECU2	ECU1	ENDP 2
84.	ECU1	DCU1.1	POLL
85.	DCU1.1	DCU1.2	POLL
86.	DCU1.2	DCU1.3	POLL
87.	DCU1.3	DCU1.4	POLL
88.	DCU1.4	Next DCU	POLL (Transmission fails)
89.	DCU1.4	DCU2.4	ARE YOU THERE?
90.	DCU2.4	DCU1.4	YES
91.	DCU1.4	DCU1.3	NBIO 0
92.	DCU1.3	DCU2.3	ARE YOU THERE? (Transmission fails)
93.	DCU1.3	DCU1.2	LBIO 0
94.	DCU1.2	DCU1.1	LBIO 1
95.	DCU1.1	ECU1	LBIO 2
96.	ECU1	SCU	LBIO 3,0
97.	SCU	System	LBIO 3,0; The system interprets this to mean that DCU1.3 could not communicate with the DCU to its left. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 is attached is open. Since this door is authorized to be open, the event is logged but the alarm is not sounded.
98.	DCU1.3	DCU1.2	NBIO 0
99.	DCU1.2	DCU2.2	ARE YOU THERE?

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
100.	DCU2.2	DCU1.2	YES
101.	DCU1.2	DCU1.1	NBIO 2
102.	DCU1.1	DCU2.1	ARE YOU THERE?
103.	DCU2.1	DCU1.1	YES
104.	DCU1.1	ECU1	NBIO 3
105.	ECU1	SCU	NBIO 4,0
106.	ECU1	SCU	ENDP 3
107.	SCU	System	ENDP 3; The system interprets this to mean that the polling of 4 columns has been completed. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.

Case 3 - A single Unauthorized Door is Open

[0069] The door to which DCU2.3 is attached is open. This door has not been authorized to be open.

	SOURCE	DEST.	MESSAGE CONTENTS
1.	System	SCU	POLL
2.	SCU	Right Link	POLL (Transmission fails)
3.	SCU	ECU1	POLL
4.	ECU1	ECU2	POLL
5.	ECU2	ECU3	POLL
6.	ECU3	ECU4	POLL
7.	ECU4	Next ECU	POLL (Transmission fails)
8.	ECU4	DCU4.1	POLL
9.	DCU4.1	DCU4.2	POLL
10.	DCU4.2	DCU4.3	POLL
11.	DCU4.3	DCU4.4	POLL
12.	DCU4.4	Next DCU	POLL (Transmission fails)
13.	DCU4.4	DCU3.4	ARE YOU THERE?
14.	DCU3.4	DCU4.4	YES
15.	DCU4.4	DCU4.3	NBIO 0
16.	DCU4.3	DCU3.3	ARE YOU THERE?
17.	DCU3.3	DCU4.3	YES
18.	DCU4.3	DCU4.2	NBIO 1
19.	DCU4.2	DCU3.2	ARE YOU THERE?
20.	DCU3.2	DCU4.2	YES

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
21.	DCU4.2	DCU4.1	NBIO 2
22.	DCU4.1	DCU3.1	ARE YOU THERE?
23.	DCU3.1	DCU4.1	YES
24.	DCU4.1	ECU4	NBIO 3
25.	ECU4	ECU3	NBIO 4,0
26.	ECU3	ECU2	NBIO 4,1
27.	ECU2	ECU1	NBIO 4,2
28.	ECU1	SCU	NBIO 4,3
29.	SCU	System	NBIO 4,3; The system interprets this to mean that DCU3.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
30.	ECU4	ECU3	ENDP 0
31.	ECU3	DCU3.1	POLL
32.	DCU3.1	DCU3.2	POLL
33.	DCU3.2	DCU3.3	POLL
34.	DCU3.3	DCU3.4	POLL
35.	DCU3.4	Next DCU	POLL (Transmission fails)
36.	DCU3.4	DCU4.4	ARE YOU THERE?
37.	DCU4.4	DCU3.4	YES
38.	DCU3.4	DCU2.4	ARE YOU THERE?
39.	DCU2.4	DCU3.4	YES
40.	DCU3.4	DCU3.3	NBIO 0
41.	DCU3.3	DCU4 3	ARE YOU THERE?
42.	DCU4.3	DCU3.3	YES
43.	DCU3.3	DCU2.3	ARE YOU THERE? (Transmission fails)
44.	DCU3.3	DCU3.2	RBIO 0
45.	DCU3.2	DCU3.1	RBIO 1
46.	DCU3.1	ECU3	RBIO 2
47.	ECU3	ECU2	RBIO 3,0
48.	ECU2	ECU1	RBIO 3,1
49.	ECU1	SCU	RBIO 3,2
50.	SCU	System	RBIO 3,2; The system interprets this to mean that DCU3.3 could not communicate with the DCU to its right. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 has been attached is open. Since this door is not authorized to open, the system logs the event and souds the alarm.

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
51.	DCU3.3	DCU3.2	NBIO 1
52.	DCU3.2	DCU4.2	ARE YOU THERE?
53.	DCU4.2	DCU3.2	YES
54.	DCU3.2	DCU2.2	ARE YOU THERE?
55.	DCU2.2	DCU3.2	YES
56.	DCU3.2	DCU3.1	NBIO 2
57.	DCU3.1	DCU4.1	ARE YOU THERE?
58.	DCU4.1	DCU3.1	YES
59.	DCU3.1	DCU2.1	ARE YOU THERE?
60.	DCU2.1	DCU3.1	YES
61.	DCU3.1	ECU3	NBIO 3
62.	ECU3	ECU2	NBIO 4,0
63.	ECU2	ECU1	NBIO 4,1
64.	ECU1	SCU	NBIO 4,2
65.	SCU	System	NBIO 4,2; The system interprets this to mean that DCU3.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
66.	ECU3	ECU2	ENDP 1
67.	ECU2	DCU2.1	POLL
68.	DCU2.1	DCU2.2	POLL
69.	DCU2.2	DCU2.3	POLL (Transmission fails)
70.	DCU2.2	DCU3.2	ARE YOU THERE?
71.	DCU3.2	DCU2.2	YES
72.	DCU2.2	DCU1.2	ARE YOU THERE?
73.	DCU1.2	DCU2.2	YES
74.	DCU2.2	DCU2.1	NBIO 0
75.	DCU2.1	DCU3.1	ARE YOU THERE?
76.	DCU3.1	DCU2.1	YES
77.	DCU2.1	DCU1.1	ARE YOU THERE?
78.	DCU1.1	DCU2.1	YES
79.	DCU2.1	ECU2	NBIO 1
80.	ECU2	ECU1	NBIO 2,0
81.	ECU1	SCU	NBIO 2,1

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
82.	SCU	System	NBIO 2,1; The system interprets this to mean that DCU2.2 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 has been attached is open. Since this door is not authorized to open the system logs the event and sounds that alarm.
83.	ECU2	ECU1	ENDP 2
84.	ECU1	DCU1.1	POLL
85.	DCU1.1	DCU1.2	POLL
86.	DCU1.2	DCU1.3	POLL
87.	DCU1.3	DCU1.4	POLL
88.	DCU1.4	Next DCU	POLL (Transmission fails)
89.	DCU1.4	DCU2.4	ARE YOU THERE?
90.	DCU2.4	DCU1.4	YES
91.	DCU1.4	DCU1.3	NBIO 0
92.	DCU1.3	DCU2.3	ARE YOU THERE? (Transmission fails)
93.	DCU1.3	DCU1.2	LBIO 0
94.	DCU1.2	DCU1.1	LBIO 1
95.	DCU1.1	ECU1	LBIO 2
96.	ECU1	SCU	LBIO 3,0
97.	SCU	System	LBIO 3,0; The system interprets this to mean that DCU1.3 could not communicate with the DCU to its left. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 is attached is open. Since this door is not authorized to open, the system logs the event and sounds the alarm.
98.	DCU1.3	DCU1.2	NBIO 0
99.	DCU1.2	DCU2.2	ARE YOU THERE?
100.	DCU2.2	DCU1.2	YES
101.	DCU1.2	DCU1.1	NBIO 2
102.	DCU1.1	DCU2.1	ARE YOU THERE?
103.	DCU2.1	DCU1.1	YES
104.	DCU1.1	ECU1	NBIO 3
105.	ECU1	SCU	NBIO 4,0
106.	ECU1	SCU	ENDP 3
107.	SCU	System	ENDP 3; The system interprets this to mean that the polling of 4 columns has been completed. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.

Case 4 Two Doors Open

[0070] The door to which DCU2.3 is attached is open with authorization. The door to which DCU2.4 has been attached

is open without authorization.

	SOURCE	DEST.	MESSAGE CONTENTS
1.	System	SCU	POLL
2.	SCU	Right Link	POLL (Transmission fails)
3.	SCU	ECU1	POLL
4	ECU1	ECU2	POLL
5.	ECU2	ECU3	POLL
6.	ECU3	ECU4	POLL
7.	ECU4	Next ECU	POLL (Transmission fails)
8.	ECU4	DCU4.1	POLL
9.	DCU4.1	DCU4.2	POLL
10.	DCU4.2	DCU4.3	POLL
11.	DCU4.3	DCU4.4	POLL
12.	DCU4.4	Next DCU	POLL (Transmission fails)
13.	DCU4.4	DCU3.4	ARE YOU THERE?
14.	DCU3.4	DCU4.4	YES
15.	DCU4.4	DCU4.3	NBIO 0
16.	DCU4.3	DCU3.3	ARE YOU THERE?
17.	DCU3.3	DCU4.3	YES
18.	DCU4.3	DCU4.2	NBIO 1
19.	DCU4.2	DCU3.2	ARE YOU THERE?
20.	DCU3.2	DCU4.2	YES
21.	DCU4.2	DCU4.1	NBIO 2
22.	DCU4.1	DCU3.1	ARE YOU THERE?
23.	DCU3.1	DCU4.1	YES
24.	DCU4.1	ECU4	NBIO 3
25.	ECU4	ECU3	NBIO 4,0
26.	ECU3	ECU2	NBIO 4,1
27.	ECU2	ECU1	NBIO 4,2
28.	ECU1	SCU	NBIO 4,3
29.	SCU	System	NBIO 4,3; The system interprets this to mean that DCU4.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
30.	ECU4	ECU3	ENDP 0
31.	ECU3	DCU3.1	POLL

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
32.	DCU3.1	DCU3.2	POLL
33.	DCU3.2	DCU3.3	POLL
34.	DCU3.3	DCU3.4	POLL
35.	DCU3.4	Next DCU	POLL (Transmission fails)
36.	DCU3.4	DCU4.4	ARE YOU THERE?
37	DCU4.4	DCU3.4	YES
38.	DCU3.4	DCU2.4	ARE YOU THERE? (Transmission fails)
39.	DCU3.4	DCU3.3	RBIO 0
40.	DCU3.3	DCU3.2	RBIO 1
41.	DCU3.2	DCU3.1	RBIO 2
42.	DCU3.1	ECU3	RBIO 3
43.	ECU3	ECU2	RBIO 4,0
44.	ECU2	ECU1	RBIO 4,1
45.	ECU1	SCU	RBIO 4,2
46.	SCU	System	RBIO 4,2; The system interprets this to mean that DCU3.4 could not communicate with the DCU to its right. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.4 is attached is open. Since this door is not authorized to be open, the event is logged and the alarm is sounded.
47.	DCU3.4	DCU3.3	NBIO 0
48.	DCU3.3	DCU4.3	ARE YOU THERE?
49.	DCU4.3	DCU3.3	YES
50.	DCU3.3	DCU2.3	ARE YOU THERE? (Transmission fails)
51.	DCU3.3	DCU3.2	RBIO 0
52.	DCU3.2	DCU3.1	RBIO 1
53.	DCU3.1	ECU3	RBIO 2
54.	ECU3	ECU2	RBIO 3,0
55.	ECU2	ECU1	RBIO 3,1
56.	ECU1	SCU	RBIO 3,2
57.	SCU	System	RBIO 3,2; The system interorets this to mean that DCU3.3 could not communicate with the DCU to its right. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 is attached is open. Because this door is authorized to open, the system logs the event but does not sound the alarm.
58.	DCU3.3	DCU3.2	NBIO 1
59.	DCU3.2	DCU4.2	ARE YOU THERE?
60.	DCU4.2	DCU3.2	YES
61.	DCU3.2	DCU2.2	ARE YOU THERE?
62.	DCU2.2	DCU3.2	YES

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
63.	DCU3.2	DCU3.1	NBIO 2
64.	DCU3.1	DCU4.1	ARE YOU THERE?
65.	DCU4.1	DCU3.1	YES
66.	DCU3.1	DCU2.1	ARE YOU THERE?
67.	DCU2.1	DCU3.1	YES
68.	DCU3.1	ECU3	NBIO 3
69.	ECU3	ECU2	NBIO 4,0
70.	ECU2	ECU1	NBIO 4,1
71.	ECU1	SCU	NBIO 4,2
72.	SCU	System	NBIO 4,2; The system interprets this to mean that DCU3.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
73.	ECU3	ECU2	ENDP 1
74.	ECU2	DCU2.1	POLL
75.	DCU2.1	DCU2.2	POLL
76.	DCU2.2	DCU2.3	POLL (Transmission fails)
77.	DCU2.2	DCU3.2	ARE YOU THERE?
78.	DCU3.2	DCU2.2	YES
79.	DCU2.2	DCU1.2	ARE YOU THERE?
80.	DCU1.2	DCU2.2	YES
81.	DCU2.2	DCU2.1	NBIO 0
82.	DCU2.1	DCU3.1	ARE YOU THERE?
83.	DCU3.1	DCU2.1	YES
84.	DCU2.1	DCU1.1	ARE YOU THERE?
85.	DCU1.1	DCU2.1	YES
86.	DCU2.1	ECU2	NBIO 1
87.	ECU2	ECU1	NBIO 2,0
88.	ECU1	SCU	NBIO 2,1
89.	SCU	System	NBIO 2,1; The system interprets this to mean that DCU2.2 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 is attached is open. Since this door is authorized to be open, the system logs the event but does not sound the alarm.
90.	ECU2	ECU2	ENDP

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
91.	ECU1	DCU1.1	POLL
92.	DCU1.1	DCU1.2	POLL
93.	DCU1.2	DCU1.3	POLL
94.	DCU1.3	DCU1.4	POLL
95.	DCU1.4	Next DCU	POLL (Transmission fails)
96.	DCU1.4	DCU2.4	ARE YOU THERE? (Transmission fails)
97.	DCU1.4	DCU1.3	LBIO 0
98.	DCU1.3	DCU1.2	LBIO 1
99.	DCU1.2	DCU1.1	LBIO 2
100.	DCU1.1	ECU1	LBIO 3
101.	ECU1	SCU	LBIO 4.0
102.	SCU	System	LBIO 4,0; The system interprets this to mean that DCU1.4 could not communicate with the DCU to its right. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.4 is attached is open. Since this door is not authorized to be open, the event is logged and the alarm is sounded.
103.	DCU1.4	DCU1.3	NBIO 0
104.	DCU1.3	DCU2.3	ARE YOU THERE? (Transmission fails)
105.	DCU1.3	DCU1.2	LBIO 0
106.	DCU1.2	DCU1.1	LBIO 1
107.	DCU1.1	ECU1	LBIO 2
108.	ECU1	SCU	LBIO 3,0
109.	SCU	System	LBIO 3,0; The system interprets this to mean that DCU1.3 could not communicate with the DCU to its left. Knowing that the current topology is a 4 by 4 matrix, the system concludes that the door to which DCU2.3 is attached is open. Since this door is authorized to be open, the event is logged but the alarm is not sounded.
110.	DCU1.3	DCU1.2	NBIO 0
111.	DCU1.2	DCU2.2	ARE YOU THERE?
112.	DCU2.2	DCU1.2	YES
113.	DCU1.2	DCU1.1	NBIO 2
114.	DCU1.1	DCU2.1	ARE YOU THERE?
115.	DCU2.1	DCU1.1	YES
116.	DCU1.1	ECU1	NBIO 3
117.	ECU1	SCU	NBIO 4,0
118.	SCU	System	NBIO 3,0; The system interprets this to mean that DCU1.4 could not communicate with the DCU above it. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.
119.	ECU1	SCU	ENDP 3

(continued)

	SOURCE	DEST.	MESSAGE CONTENTS
120.	SCU	System	ENDP 3; The system interprets this to mean that the polling of 4 columns has been completed. Knowing that the current topology is a 4 by 4 matrix, the system does not sound the alarm.

Claims

1. A system for monitoring a multiplicity of doors comprising:

at least one optical transceiver (40) mounted on each of the multiplicity of doors; and
communication apparatus (28) for communicating with said at least one optical transceiver mounted on each of the multiplicity of doors thereby to verify their position, **characterized in that** said communication apparatus is operative to communicate with the at least one optical transceiver on each of said multiplicity of doors via plural alternative serial communications pathways and **in that** at least one of said plural pathways extends via optical transceivers mounted on a plurality of different doors.

2. A system according to claim 1 and wherein said at least one transceiver comprises, for at least some of said multiplicuty of doors, a plurality of optical transmitters and receivers operative in a plurality of different directions.

3. A system according to claim 1 and wherein said at least one transceiver on each of said plurality of doors is autonomously powered.

4. A system according to claim 1 and wherein said at least one transceiver comprises at least one light emitting diode and light sensor.

5. A system according to claim 1 and wherein said at least one transceiver comprises a microprocessor.

6. A system according to claim 1 and wherein said at least one transceiver is operative to provide an indication of an open door or inoperative transceiver downstream thereof in a communications chain.

7. A system according to claim I and wherein said communications apparatus comprises a personal computer.

8. A system according to claim 1 and wherein said communications apparatus communicates with said transceivers via at least two communications interfaces.

9. A system according to claim 1 and wherein said plurality of doors are doors of a bank of safe deposit boxes.

10. A system according to claim 1 and also comprising apparatus for logging door openings and inoperative transceivers on a time based log.

Patentansprüche

1. System zur Überwachung einer Vielzahl von Türen, das umfaßt:

wenigstens einen optischen Sendeempfänger (40), der an jeder der Vielzahl von Türen angebracht ist; und eine Verbindungsvorrichtung (28), die mit dem wenigstens einen optischen Sendeempfänger in Verbindung steht, der an jeder der Vielzahl von Türen angebracht ist, um so ihre Stellung zu überprüfen, **dadurch gekennzeichnet, daß** die Verbindungsvorrichtung mit dem wenigstens einen optischen Sendeempfänger an jeder der Vielzahl von Türen über mehrere alternative serielle Verbindungswege in Verbindung steht, und daß wenigstens einer der mehreren Wege über optische Sendeempfänger verläuft, die an einer Vielzahl verschiedener Türen angebracht sind.

2. System nach Anspruch 1, wobei der wenigstens eine Sendeempfänger für wenigstens einige der Vielzahl von

Türen eine Vielzahl optischer Sender und Empfänger umfaßt, die in einer Vielzahl verschiedener Richtungen wirksam sind.

3. System nach Anspruch 1, wobei der wenigstens eine Sendeempfänger an jeder der Vielzahl von Türen autonom gespeist wird.

4. System nach Anspruch 1, wobei der wenigstens eine Sendeempfänger wenigstens eine Leuchtdiode und einen Lichtsensor umfaßt.

5. System nach Anspruch 1, wobei der wenigstens eine Sendeempfänger einen Mikroprozessor umfaßt.

6. System nach Anspruch 1, wobei der wenigstens eine Sendeempfänger eine offene Tür oder einen nicht in Funktion befindlichen Sendeempfänger stromab davon in einer Verbindungskette anzeigt.

7. System nach Anspruch 1, wobei die Verbindungsvorrichtung einen Personalcomputer umfaßt.

8. System nach Anspruch 1, wobei die Verbindungsvorrichtung mit den Sendeempfängern über wenigstens zwei Verbindungsschnittstellen in Verbindung steht.

9. System nach Anspruch 1, wobei die Vielzahl von Türen die Türen einer Gruppe von Schließfächern sind.

10. System nach Anspruch 1, das des weiteren eine Vorrichtung zum Protokollieren von Türöffnungsvorgängen und nicht in Funktion befindlichen Sendeempfängern in einem Zeitprotokoll umfaßt.

Revendications

1. Système pour surveiller une multiplicité de portes comprenant
au moins un émetteur-récepteur (40) optique monté sur chacune des portes de la multiplicité de portes; et
un appareil de communication (28) pour communiquer avec ledit au moins un émetteur-récepteur optique monté sur chacune des portes de la multiplicité de portes afin de vérifier leur position, **caractérisé en ce que** ledit appareil de communication est adapté pour être mis en fonctionnement pour communiquer avec le au moins un émetteur-récepteur optique sur chacune desdites portes de la multiplicité de portes à travers plusieurs voies de passage de communication en série de substitution et **en ce qu'**au moins l'une desdites plusieurs voies de passage s'étend à travers d'émetteurs-récepteurs optiques montés sur une pluralité de portes différentes.

2. Système selon la revendication 1 et dans lequel ledit au moins un émetteur-récepteur comprend, pour au moins quelques unes desdites portes de la multiplicité de portes, une pluralité d'émetteurs et récepteurs optiques adaptés pour être mis en fonctionnement dans une pluralité de directions différentes.

3. Système selon la revendication 1 et dans lequel ledit au moins un émetteur-récepteur sur chacune desdites portes de la pluralité de portes est alimenté de manière autonome.

4. Système selon la revendication 1. et dans lequel ledit au moins un émetteur-récepteur comprend au moins une diode émettrice de lumière et un détecteur de lumière.

5. Système selon la revendication 1 et dans lequel ledit au moins un émetteur-récepteur comprend un microprocesseur.

6. Système selon la revendication 1 et dans lequel ledit au moins un émetteur-récepteur est adapté pour être mis en fonctionnement pour fournir une indication d'une porte ouverte ou d'un émetteur-récepteur hors fonctionnement en aval dans une chaîne de communication.

7. Système selon la revendication 1 et dans lequel ledit appareil de communication comprend un ordinateur personnel.

8. Système selon la revendication 1 et dans lequel ledit appareil de communication communique avec lesdits émetteurs-récepteurs à travers au moins deux interfaces de communication.

9. Système selon la revendication 1 et dans lequel lesdites portes de la pluralité de portes sont des portes d'un groupe de boîtes de dépôt de sécurité.

10. Système selon la revendication 1 et comprenant également un appareil pour enregistrer des ouvertures de portes et des émetteurs-récepteurs hors fonctionnement en fonction d'une table basée sur le temps.


20
22
A
B
C
D
E
F
G
8
24
7
6
26
5
4
3
2
1
ECB
32
34
SCU
28
30
28
SYSTEM MANAGER

FIG.1


SEN
LED
41
45
LED
SEN
CONTR.
47
43
50
DCU
26
40
ECU
28
46
34
44
42
ECB
SYSTEM
MANAGER
32
SCU

FIG.2


64
66
68
70
74
76
78
80
LED UP
LED RIGHT
LED DOWN
LED LEFT
SEN UP
SEN RIGHT
SEN DOWN
SEN LEFT
LED BUFFER
SENSOR BUFFER
72
62
TX REGISTER
RX REGISTER
58
60
I/O BUS
52
CPU
COMMUNICATION WAKE-UP
88
POWER SUPPLY
RF RECTIFY
SOLAR CELLS
54
ROM
RAM
86
84
56
POWER MODULE
CONTROLLER
82
50

FIG.3


114
LED
118
SEN
TO ECU
FROM ECU
136
BUFFER
112
BUFFER
116
SEN BUFFER
132
BUFFER
134
TX REGISTER
108
TX REGISTER
110
RX REGISTER
130
RX REGISTER
I/O BUS
103
SERIAL INPUT
CPU
SERIAL OUTPUT
105
102
106
ROM
RAM
104

FIG.4


R5 1K
UP
VCC
U3
LIGHT SENSOR HFD4324
C1 0.1
R6 1K
RIGHT
U4
C2 0.1
R7 1K
LEFT
U5
C3 0.1
R8 1K
DOWN
U6
C4 0.1
A
B
C
D

FIG.5A


VCC
C10
0.1
31
EA/VP
C7
27PF
19
X1
X1
8MHz
C8
27PF
18
X2
C9
VCC
10U
R9
8.2K
9
RESET
12
INT0
13
INT1
14
T0
15
T1
87C51
U1
1
P1.0
2
P1.1
3
P1.2
4
P1.3
5
P1.4
6
P1.5
7
P1.6
8
P1.7
P0.0 39
P0.1 38
P0.2 37
P0.3 36
P0.4 35
P0.5 34
P0.6 33
P0.7 32
P2.0 21
P2.1 22
P2.2 23
P2.3 24
P2.4 25
P2.5 26
P2.6 27
P2.7 28
RD 17
WR 16
PSEN 29
ALE/P 30
TXD 11
RXD 10
A
B
C
D
E
F
G
H
J
K
D5
2
1
1N914
SW1
VCC
SC1
6V
C5
47UF
POWER

FIG.5B


UP
VCC
D2
LED
CQZ48
R2 220
VCC
C6
0.1
2
3
4
5
6
7
8
9
19
1
A1
A2
A3
A4
A5
A6
A7
A8
G
DIR
U2
74HC245
B1
B2
B3
B4
B5
B6
B7
B8
18
17
16
15
14
13
12
11
E
F
G
H
J
K
J1
1
2
3
RS-232 3 PIN CON.

FIG.5C


START
INITIALIZE
REGISTER THAT NO DOOR IS OPEN & THAT NO DOOR IS AUTHORIZED TO OPEN
WAIT FOR AN EVENT TO OCCUR
BRANCH ACCORDING TO TYPE OF EVENT
HANDLE TIMER EVENT
HANDLE USER INPUT
HANDLE RECEPTION OF MESSAGE FROM SCU

FIG.6A


START
HAS IT BEEN TOO LONG SINCE THE LAST MESSAGE RECEPTION ?
YES
NO
LOG THE REPORT A COMMUNICATION FAILURE. SOUND THE ALARM
TRANSMIT A REQUEST TO THE SCU TO PERFORM A BLOCK POLL
RETURN FROM SUBROUTINE

FIG.6B


START
RECEIVE MESSAGE FROM SCU
BRANCH ACCORDING TO TYPE OF MESSAGE
HANDLE NBIO MESSAGE
HANDLE RBIO MESSAGE
HANDLE LBIO MESSAGE
HANDLE ENDP MESSAGE
RETURN FROM SUBROUTINE

FIG.6C


START
HANDLE BOX IS OPEN EVENT
BOX COORDINATE IS:
COL-1 , ROW
RETURN FROM SUBROUTINE

FIG.6D


START
HANDLE BOX IS OPEN EVENT
BOX COORDINATE IS:
COL+1 , ROW
RETURN FROM
SUBROUTINE

FIG.6E


START
IS
ROW+1 A
VALID ROW
?
NO
YES
HANDLE BOX IS OPEN.
BOX COORDINATE IS :
COL , ROW
RETURN FROM
SUBROUTINE

FIG.6F

FIG.6G


START
IS COL+1 THE NUMBER OF COLUMNS IN THE SYSTEM ?
YES
NO
LOG AND SOUND THE ALARM
RETURN FROM SUBROUTINE

FIG.6H


START
GET INPUT FROM USER
BRANCH ACCORDING TO REQUEST
AUTHORIZE DOOR X
UNAUTHORIZE DOOR X
REGISTER THAT DOOR X IS AUTHORIZED TO OPEN
REGISTER THAT DOOR X IS NO LONGER AUTHORIZED TO OPEN
RETURN FROM SUBROUTINE


START
IS THE BOX AT ROW, COL AUTHORIZED TO OPEN ?
NO
YES
SOUND AN ALARM
LOG THE EVENT OF BOX ROW,COL OPEN
RETURN FROM SUBROUTINE

FIG.6I


START
INITIALIZE
WAIT FOR POLL COMMAND FROM SYSTEM MANAGER 34
CONDUCT POLLING OF BLOCK 20

FIG.7A


TRANSMIT POLL MESSAGE TO FIRST ECU
AWAIT MESSAGE FROM ECU
WAS MESSAGE RECEIVED OK ?
NO
YES
TRANSMIT THE SAME MESSAGE TO THE SYSTEM MANAGER 34
WAS MESSAGE OF TYPE ENDP ?
NO
YES
RETURN FROM SUBROUTINE

FIG.7B


START
INITIALIZE
WAIT FOR WAKE-UP
HANDLE START-BIT FROM HORIZONTAL LINK HX

FIG.8A


START
RECEIVE MESSAGE FROM LINK HX
WAS WORD RECEIVED SUCCESSFULLY ?
NO
YES
BRANCH ACCORDING TO TYPE OF MESSAGE
HANDLE NBIO MESSAGE FROM LINK HX
HANDLE RBIO MESSAGE FROM LINK HX
HANDLE LBIO MESSAGE FROM LINK HX
HANDLE POLL MESSAGE FROM LINK HX
HANDLE ENDP MESSAGE FROM LINK HX
RETURN FROM SUBROUTINE

FIG.8B


START
TRANSMIT SAME TYPE OF MESSAGE (i.e. NBIO OR RBIO OR LBIO) WITH DATA COL+1, ROW TO LINK 1 - HX (i.e. THE OPPOSITE LINK)
RETURN FROM SUBROUTINE

FIG.8C


START
PERFORM DCU COLUMN POLL
TRANSMIT AN ENDP MESSAGE WITH DATA COL+1 TO LINK 1-HX (OPPOSITE LINK)
RETURN FROM SUBROUTINE

FIG.8D


TRANSMIT A POLL MESSAGE TO LINK 1-HX (OPPOSITE LINK)
WAS TRANSMISSION SUCCESSFUL ?
YES
NO
PERFORM DCU COLUMN POLL : TRANSMIT RESULTS TO LINK 1-HX
TRANSMIT ENDP MESSAGE WITH DATA 0 TO LINK 1-HX (OPPOSITE LINK)
RETURN FROM SUBROUTINE

FIG.8E


START
TRANSMIT POLL MESSAGE TO FIRST DCU
IS TRANSMISSION SUCCESSFUL ?
NO
TRANSMIT NBIO MESSAGE WITH INDICES 0,0 TO LINK HX
YES
AWAIT MESSAGE FROM DCU
WAS MESSAGE RECEIVED SUCCESSFULLY ?
NO
YES
BRANCH ACCORDING TO MESSAGE TYPE
LBIO
RBIO
NBIO
TRANSMIT LBIO MESSAGE TO LINK HX 0, ROW+1
TRANSMIT RBIO MESSAGE TO LINK HX 0, ROW+1
TRANSMIT NBIO MESSAGE TO LINK HX 0, ROW+1
RETURN FROM SUBROUTINE

FIG.8F

FIG.9A


POWER ON/
RESET
INITIALIZE
WAIT FOR
WAKE-UP
START BIT FROM
LINK HX
BRANCH
ACCORDING TO
REASON FOR
WAKE-UP
START BIT FROM
LINK VX
HANDLE START
BIT FROM
LINK HX
HANDLE START
BIT FROM
LINK VX


START
RECEIVE MESSAGE
FROM LINK HX
TRANSMIT MESSAGE
BACK TO LINK HX
RETURN FROM
SUBROUTINE

FIG.9B


START
RECEIVE MESSAGE FROM LINK VX
MESSAGE RECEIVED OK ?
NO
YES
BRANCH ACCORDING TO MESSAGE TYPE
HANDLE POLL MESSAGE FROM LINK VX
HANDLE NBIO MESSAGE FROM LINK VX
HANDLE RBIO MESSAGE FROM LINK VX
HANDLE LBIO MESSAGE FROM LINK VX
RETURN FROM SUBROUTINE

FIG.9C


START
TRANSMIT POLL MESSAGE TO LINK 1-VX (THE OPPOSITE LINK)
WAS TRANSMIT OK ?
YES
NO
TRANSMIT STATUS OF RIGHT AND LEFT NEIGHBORS
TRANSMIT NBIO MESSAGE WITH INDEX 0 TO LINK VX (THE OPPOSITE LINK)
RETURN FROM SUBROUTINE

FIG.9D


START
READ STATUS OF RIGHT NEIGHBOR
IS RIGHT NEIGHBOR OPEN ?
NO
YES
TRANSMIT RBIO MESSAGE TO LINK VX (WITH INDEX 0)
READ STATUS OF LEFT NEIGHBOR
IS LEFT NEIGHBOR OPEN ?
NO
YES
TRANSMIT LBIO MESSAGE TO LINK VX (WITH INDEX 0)
RETURN FROM SUBROUTINE

FIG.9E


START
COMMUNICATE WITH NEIGHBOR
WAS COMMUNICATION SUCCESSFUL ?
YES
NO
RETURN INDICATION THAT NEIGHBOR IS CLOSED
RETURN INDICATION THAT NEIGHBOR IS OPEN
RETURN FROM SUBROUTINE

FIG.9F


START
TRANSMIT STATUS OF RIGHT AND LEFT NEIGHBORS
TRANSMIT NBIO MESSAGE WITH ROW+1 TO LINK 1-VX (OPPOSITE LINK)
RETURN FROM SUBROUTINE

FIG.9G


START
TRANSMIT RBIO MESSAGE WITH ROW+1 TO LINK 1-VX (OPPOSITE LINK)
RETURN FROM SUBROUTINE

FIG.9H


START
TRANSMIT LBIO MESSAGE WITH ROW+1 TO LINK 1-VX (OPPOSITE LINK)
RETURN FROM SUBROUTINE

FIG.9I